

RIGA TECHNICAL UNIVERSITY

By-Product of the Wood Pulp Industry - Tall Oil -**Utilisation for Acrylate Synthesis**

Ralfs Pomilovskis^a, Inese Mierina^a, Eliza Kaulina^{a,b}, Anda Fridrihsone^b and Mikelis Kirpluks^b ^aInstitute of Technology of Organic Chemistry, Riga Technical University, P. Valdena St. 3/7, LV-1048 Riga, Latvia ^bPolymer Laboratory, Latvian State Institute of Wood Chemistry, Dzerbenes St. 27, Riga LV-1006, Latvia E-mail: ralfs.pomilovskis@gmail.com

To change the existing economic climate into a greener economy, it is essential to adapt the processing of forest bio-resources into biochemicals. Distilled tall oil, a byproduct of the Kraft process, mainly contains oleic and linoleic acid making it attractive for the synthesis of a variety of high-added value bio-based substances. Recently, much attention has been paid to the synthesis of multifunctional bio-based acrylates for polymer production. We report an approach for synthesising acrylates HO² from tall oil using epoxidation, oxirane ring-opening with a polyfunctional polyol, and following hydroxyl group acrylation with acryloyl chloride.

Synthesis of tall oil-based acrylate

Previously synthesized polyol, E^{IR}TOFA_BD or E^{IR}TOFA_TMP, and a corresponding amount of ethyl acetate and triethylamine were added to a round bottom flask with four necks equipped with a stirrer, thermocouple, Oxirane opening and carboxyl group esterification with 1,4-butanediol (BD) HO、 E^{IR}TOFA_BD Acrylation with acryloyl chloride



Methods of analysis

The proton nuclear magnetic resonance (¹H-NMR) spectra were recorded with a Bruker spectrometer (Bruker BioSpin, Fällanden, Switzerland) at 500 and 126 MHz, respectively. Deuterated chloroform (CDCl₃) was used as the solvent. The ¹H-NMR spectra were used for the determination of acrylic group content using 1,2,3 trimethoxybenzene as an internal standard. matrix-assisted laser The desorption/ionization-time flight of measurements were carried out using the



Matrix-assisted laser desorption/ionization-time of flight spectra of tall oil-based polyol and tall

Matrix-assisted laser desorption/ionization-time of flight spectra of tall oil-based polyol and tall

oil-based acrylates: a) E^{IR}TOFA_BD; b) E^{IR}TOFA_BD_Acryl

oil-based acrylates: a) E^{IR}TOFA TMP; b) E^{IR}TOFA TMP Acryl

Conclusions

Although synthesised E^{IR}TOFA-based polyols consist of a mixture of various derivatives, they contain free hydroxyl groups, which can be converted to acrylic groups. Considering the proton nuclear magnetic resonance data and Matrix-assisted laser desorption/ionization-time of flight spectra, the synthesised acrylates from tall oil fatty acids-based polyols contain several acrylic groups required for polymerisation according to the Michael reaction mechanism. E^{IR}TOFA_BD_Acryl contains 0.0039 mol/g acrylic groups, but E^{IR}TOFA_TMP_Acryl contains 0.0035 mol/g acrylic groups. The obtained tall oil polyol-based acrylates are suitable for polymer synthesis by the Michael reaction. Moreover, the synthesised tall oil polyol-based acrylates are promising in producing other polymers, for example, in UV-initiated free radical polymerisation in the production of coatings.

Acknowledgements

This work has been supported by the European Social Fund within the Project No 8.2.2.0/20/I/008 «Strengthening of PhD students and NATIONAL academic personnel of Riga Technical University and BA School of Business and Finance in the strategic fields of specialization» of the Specific Objective 8.2.2 «To Strengthen Academic Staff of Higher Education Institutions in Strategic Specialization Areas» of the Operational Programme «Growth and Employment». This publication was supported by Riga Technical University's Doctoral Grant programme.

A special thank you goes to researcher PhD Olga Kockova (Institute of Macromolecular Chemistry CAS, Prague 16200, Czech Republic) for her contribution to Matrix-assisted laser desorption/ionization-time of flight spectra.



INVESTING IN YOUR FUTURE